



Material:

- **Mounting Frame** : Aluminum with Powder coating finish. Mount on the wall.
- **Tissue Roll Holder** : ABS with raw finish. To hold tissue roll.
- **Holding Pin** : Brass with a Chrome-Plated finish. To hold tissue roll holder on mounting frame.

Installation:

- Mount the mounting frame on the wall with the help of the screw set provided.
- Four mounting holes are provided on the frame for screws. Holes are in slot shape to adjust the frame during mounting on the wall.
- Attach the tissue roll holder on a mounting frame by inserting the holding pin (fix in holder bar) in the hole given in the frame. Attach both tissue roll holders with frame.
- Before attaching tissue roll holder with frame mount tissue roll on the holder.
- It holds a tissue roll of a maximum length of 94mm (3.7 inches).

Specification:

- Aluminum Mounting frame with powder coating finish has Sharpless edges. The thickness of the frame is uniform through all (3mm approx). SS 304 Mounting screw provided with ABS sleeves for proper attachment in the material. Grooves are given on holding pin for easily removing of the holder from mounting frame. Holding pin have a diameter of 5mm. ABS Tissue roll holder with raw finish have holding pins of diameter 5mm to attach in Mounting frame. Mounting holes are represented by C where screws are to be fixed.